



Instruction Manual:

Congratulations on your purchase of Gun Casket™, The Safe Alternative™. You are now officially cooler than your friends who don't have one. You can rest in peace, knowing your shotgun is safely stored, but quickly accessible when you need it. Review all of the instructions, disclaimers, and warnings before using the Gun Casket. **IF YOU DO NOT AGREE WITH THE TERMS AND PROVISIONS STATED HEREIN, PLEASE RETURN THE UNUSED PRODUCT FOR A REFUND.**

Your Gun Casket is designed to provide years of worry free service. Please retain these instructions and the separate instructions from the lock manufacturer. Together they include maintenance, cleaning, operating and combination changing instructions. If you misplace these instructions, you can download a copy from our website:
www.guncasket.com.

Gun Casket™, the casket shape of the box, and the silver metallic anodized color resembling a casket, the slogan "The Safe Alternative," and the Gun Casket logo are trademarks of Gun Casket, LLC. The Gun Casket logo is a copyright of Gun Casket. Gun Casket safes are patent pending.

Maintenance:

Your Gun Casket™ is designed to be virtually maintenance free. The main body of your Gun Casket is made of high quality anodized aluminum, one of the hardest materials known to man. The locking mechanism is made with the highest grade materials to give you consistent, reliable service. Keep your Gun Casket clean and dry and it will provide you with years of reliable, worry free service.

Cleaning:

If your Gun Casket needs cleaning use warm water with mild soap and a damp rag. To avoid corrosion on moving parts, immediately wipe off any excess water from the hinge and lock areas. Do not use abrasive pads when cleaning; they can scratch the surface leaving dull spots. For stubborn stains use a more aggressive cleaning solution made specifically for anodized aluminum. Never oil the hinge or locking mechanisms.

Operating:

Warning: For your own safety, **you must change the lock combination prior to storing any gun in this safe.** This will ensure that your combination is private. You can easily change to a new combination using any number of buttons you wish in any order. Choose your new combination and **write it down and put it in a safe place; no genius, not inside your Gun Casket, though that is a safe place.** If your combination is lost or forgotten you can use the key override. If you lose the key, you will have real problems. That one is worth repeating: **IF YOUR COMBINATION IS LOST OR FORGOTTEN AND YOU LOSE THE KEY, YOU WILL NOT BE ABLE TO OPEN THE BOX WITHOUT DESTROYING IT.** Forcing your Gun Casket open will void the warranty. It will also destroy your Gun Casket. Think of a combination that's easy for you to remember but impossible for someone else to guess. Do not use a simple combination, remember, you are putting a gun inside the Gun Casket. You are trying to keep people out, especially children. Save the easy codes for your bank account.

Please refer to the lock manufacturer's instructions for changing your combination lock, and all other instructions related to the use of the lock.

LIMITED WARRANTY

Warranty: One (1) year limited warranty from date of purchase for product(s) defects in material and workmanship.

Warranty Compliance: This warranty applies provided there is compliance with all use instructions supplied by the Company and, provided further, that the product has been subject to normal use without any misuse, neglect, modification, or the occurrence of accidental damage.

Product(s) Return: In the event of a defect in materials or workmanship discovered by the initial retail customer is covered by this warranty, the purchaser shall return within the one (1) year warranty period, at purchaser's sole expense, the product to the Company for repair or replacement. The Company in its sole discretion, may use functionally equivalent, reconditioned, refurbished, pre-owned or new product parts to effectuate any needed repairs. Repair or replacement shall be at the election of the Company. Repair or replacement of any covered defect hereunder shall fulfill all of the Company's liability and responsibility under this Limited Warranty. **THE FOREGOING IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES. THIS LIMITED WARRANTY SPECIFICALLY EXCLUDES ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.** The purchaser's sole remedy in contract or tort shall be the repair or replacement of the product and under no circumstances shall the Company be liable to the purchaser or any other person for any consequential, incidental, economic loss, injury to person or property, direct, indirect, general or special damages arising out of any breach of warranty. Customer specifically acknowledges that in no event shall the Company's liability exceed the original cost of the product.

Warranty Authorization: This warranty and solutions set forth above are exclusive and in lieu of all others, oral or written, expressed or implied. No dealer, distributor, agent or employee is authorized to make any modification or addition to this warranty.

Notice: Installation of the product with any unapproved accessorial item or product may invalidate the Gun Casket Limited Product Warranty.

NOTE: THE COMPANY CANNOT GUARANTY THAT YOUR SHOTGUN WILL FIT INSIDE OF THE PRODUCT. THE COMPANY HAS ENDEAVORED TO MANUFACTURE A PRODUCT THAT CAN STORE MOST STANDARD SIZED SHOTGUNS. THE COMPANY IS NOT RESPONSIBLE IF PURCHASER'S SHOTGUN CANNOT BE PLACED INSIDE THE PRODUCT. THE COMPANY, IN ITS SOLE DISCRETION, MAY, THOUGH IT IS NOT OBLIGATED TO, CHOOSE TO REFUND A PURCHASER IF HIS OR HER SHOTGUN DOES NOT FIT INSIDE THE PRODUCT. HERE'S A HINT, IF YOUR GUN DOES NOT EASILY FIT, DON'T TRY TO FORCE IT INTO THE PRODUCT AS YOU MAY DAMAGE THE PRODUCT OR YOUR GUN.

DISCLAIMER

The Company will not be responsible for the results of careless handlings, unauthorized repairs, modifications, and/or adjustments, corrosion, neglect, unreasonable and/or unsafe use of the product; for any unreasonable and/or unsafe use of firearms stored in or in any way used in conjunction with the product; or for any unauthorized access to any firearms stored in the product. In addition to all of that, the Company will not be responsible if you just plain ruin your Gun Casket™.

PURCHASER SPECIFICALLY ACKNOWLEDGES AND AGREES THAT THE COMPANY ASSUMES NO RESPONSIBILITY FOR DAMAGE AND/OR INJURY OR DEATH CAUSED IN WHOLE OR IN A PART BY ANY FIREARM STORED IN OR USED IN ANY WAY IN CONJUNCTION WITH THE PRODUCT. UNDER NO CIRCUMSTANCES SHALL THE COMPANY, IT PARENTS, SUBSIDIARIES, AFFILIATES, MEMBERS, OR ASSIGNS BE RESPONSIBLE FOR INCIDENTAL, ECONOMIC LOSS, INJURY OR DEATH TO PERSON OR PROPERTY, DIRECT, INDIRECT, GENERAL OR SPECIAL DAMAGES ARISING OUT OF OR IN ANY WAY RELATED TO THE USE OF THE PRODUCT, THE STORAGE OR USE OF ANY FIREARM IN CONJUNCTION WITH THE PRODUCT, INCLUDING ANY UNSAFE HANDLING OR USE OF SAID FIREARMS OR ANY UNAUTHORIZED MODIFICATIONS TO THE PRODUCT.

If purchaser's state does not allow the Company's limited warranty or disclaimer, in whole or in part, or any other provision of this agreement, then Purchaser agrees that this disclaimer and any other provision in this agreement will be interpreted as broadly as purchaser's state allows.

WARNINGS AND NOTICES

WARNING: BECAUSE THERE IS SOME ATTORNEY OUT THERE THAT WANTS TO MAKE SOME MONEY OFF OF YOU BY ARGUING THAT YOU NEED TO BE WARNED ABOUT THE DANGERS ASSOCIATED WITH FIREARMS, TO AVOID SUCH LAWSUITS IT IS IMPORTANT FOR THE COMPANY TO REMIND YOU, THE CUSTOMER, THAT THESE SELECTED TIPS, SUGGESTIONS, AND WARNINGS ARE NOT TO BE VIEWED AS AN EXHAUSTIVE LIST OF ALL SAFETY ISSUES AND HANDLING RECOMMENDATIONS FOR FIREARM USE. THE COMPANY SPECIFICALLY REFERS THE CUSTOMER TO THE FIREARM OWNER'S MANUAL FOR HIS OR HER RESPECTIVE FIREARM FOR SUCH INFORMATION. BY PURCHASING THIS PRODUCT, CUSTOMER ACKNOWLEDGES THAT THE COMPANY DOES NOT MANUFACTURE, SELL, MARKET OR DISTRIBUTE FIREARMS AND, AS SUCH, CUSTOMER SHOULD LOOK TO THE FIREARM MANUFACTURER FOR ALL PROPER WARNINGS, SAFE USE DIRECTIONS, AND FIREARM USE HANDLING INSTRUCTIONS. CUSTOMER MAY ALSO VISIT HIS LOCAL FIREARMS DEALER FOR SUCH INFORMATION OR MAY CONTACT OTHER THIRD PARTIES OR GOVERNMENTAL AGENCIES FOR FIREARM SAFETY INFORMATION (E.G., LOCAL LAW ENFORCEMENT THE NATIONAL RIFLE ASSOCIATION AT WWW.NRA.COM, BUREAU OF ALCOHOL, TOBACCO, FIREARMS, AND EXPLOSIVES AT WWW.ATF.GOV, ETC.). THESE WEB ADDRESSES MAY CHANGE OVER TIME, IT IS UP TO YOU TO LOCATE ANY CONTACT INFORMATION OF ANY THIRD PARTY. IF YOU EVER LOSE THESE WARNINGS AND NOTICES, YOU MAY CONTACT THE COMPANY FOR ANOTHER COPY.

Purchaser should refer to the firearm manufacturer's warnings and safe handling instructions for any firearm that purchaser may use in conjunction with the product.

All firearms are potentially dangerous and should only be used by someone who has been trained in the safe use of firearms. And, again, even though everyone in the world knows that firearms are dangerous, there is bound to be some attorney who feels that you may need an extra warning about firearms. Here's an extra warning: FIREARMS CAN BE EXTREMELY DANGEROUS AND MAY CAUSE SERIOUS BODILY INJURY OR DEATH.

To make sure you *really* understand, and to show the blood sucking attorneys that the Company tried to warn you, here are a few more common warnings with respect to firearms; but again, please refer to the firearm manufacturer for the warnings and safe use recommendations of any firearm you intend to use with the product. These common warnings are not a replacement or substitute for the firearm manufacturer's warnings and safe use instructions.

- Make sure that the placement of a firearm in the product does not interfere with any controls or safety devices on the firearm.
- Do not expose the product or any firearm stored inside to extreme heat.
- Do not store the product or firearm in wet or damp conditions.
- Any pistol, shotgun, or rifle is classified as a firearm and a dangerous weapon. Injury or death to you or others may result from the unsafe or improper use.
- Wear eye protection when using any cleaning agents or solvents on any weapons stored in the product.
- Always wear eye and ear protection when using any firearm.
- Always follow the manufacturer's operating instructions of any firearms.
- Always use eye and ear protection when shooting a firearm or when in close proximity to shooting. The use of any firearm may produce noises that are a danger to hearing. (In simple terms, firearms are loud and loud noises are not good for your ears.)
- Never point a firearm at anything you do not intend to destroy.

- Use only fresh factory ammunition in your firearm. DO NOT use handloads, reloads, or remanufactured ammunition in your firearm. Only shoot cartridges or ammunition of the caliber engraved on your firearm.
- If you decide to disassemble a firearm for storage in the product, only do so as recommended and instructed by the manufacturer of the firearm. Improper disassembly and assembly will create unsafe conditions that could result in injury or death. Do not attempt to disassemble any firearm until you have received professional training and instructions as recommended by the manufacturer of the firearm.
- Always point a firearm in a safe direction. Failure to obey safety information may result in injury or death to you or others.
- Transfer this manual to any subsequent owner or user of the product.
- If you are inexperienced in the handling of firearms, obtain expert instructions before attempting to shoot any firearm.
- The manufacturer's manual of any firearm cannot take the place of proper instructions in the safety aspects of shooting, the storage and use of firearms, and the use of a firearm for self-defense. Death or severe injury to body, hands, eyes, face, other persons or property will occur with improper use of a firearm.
- Make sure the chamber and magazines of any firearms stored in the product are unloaded. Any magazines should be removed first. Even though the chamber is empty, there may be a cartridge in the magazine. Check the chamber to be sure it and the magazine are clear of any cartridges. (In other words, make sure that the firearm is unloaded and that any magazines are likewise unloaded.)
- The detainer springs, if any, in the product are under spring tension, and can cause eye or other injury if not controlled during removal. Wear protective safety glasses to reduce the risk of eye or facial injuries.
- Never touch the trigger when loading or unloading a firearm.
- No firearm is unloaded until the chamber is empty and all magazines are removed.
- Point a firearm in a safe direction at all times.
- ALWAYS FOLLOW THE FIREARM MANUFACTURER'S INSTRUCTIONS FOR THE SAFE STORAGE OF A FIREARM.
- ALWAYS FOLLOW THE MANUFACTURER'S INSTRUCTIONS FOR THE SAFE USE OF A FIREARM.
- When you squeeze the trigger of a firearm, you must expect the firearm to fire. You must take full responsibility for firing it. Your care can avoid accidental discharges and thereby prevent injury or death.
- Accidental discharges indoors always result in property damage or personal injury.
- There is no safe or recommended way to discharge a firearm in a home or apartment. Bullets can travel through floors, walls, ceilings, furniture and appliances and can still cause injury or death to persons in the house or outside of the house.
- Treat every firearm as if it is loaded, ALWAYS.
- Only load a firearm when on the range or in the field preparing to fire. Unload the firearm when leaving the range or the field, and before storing it in the product.
- Load and unload a firearm only when it is pointed in a safe direction.
- Before cleaning any firearm, make sure it is unloaded.
- Ensure that the firearm is unloaded before storing, travelling, transporting, resting it against an object, operating an ATV, entering a home, store, automobile, boat, motor home, or handing it to another person.
- Never leave unattended any loaded firearm.
- If a child finds or gains access to your firearm, tragedy or death may result. Keep every firearm secure from unintended use.
- **CHILDREN DO NOT APPRECIATE AND UNDERSTAND THAT FIREARMS CAN CAUSE DEATH OR SEVERE INJURY.**
- Store firearms and ammunition separately. Both should be kept out of the reach of children.
- Obey all laws pertaining to firearm usage and storage in the home or elsewhere.
- Obey all laws pertaining to the transportation or carrying of any firearm.

- Always wear eye protection when shooting any firearm.
- Always wear ear protection when shooting any firearm.
- Never shoot a firearm at a flat or hard surface, as bullets may ricochet.
- Do not alter or modify any firearm.
- Follow the manufacturer's instruction with respect to cleaning your firearm.
- Discharging any firearm may result in exposure to lead or other chemicals/substances known or suspected of causing birth defects, reproduction harm, cancer, or other serious physical or cognitive injuries.
- Wash your hands after discharging or cleaning a firearm. Follow all instructions provided by the manufacturer of any cleaning products used to clean your firearm.
- Some firearms can operate without a magazine.
- NOTE: THERE ARE VARYING DEGREES AND QUALITIES OF SAFES FOR FIREARMS RANGING FROM THIN SHEET METAL BOXES TO 2000 POUND FIREPROOF SAFES OFFERING THE PROTECTIONS OF FORT KNOX. PLEASE THOROUGHLY EXAMINE THE GUN CASKET™. IF YOU DO NOT BELIEVE THAT THE GUN CASKET SAFE MEETS YOUR NEEDS AND EXPECTATIONS FOR SECURELY STORING YOUR WEAPON, THE COMPANY RECOMMENDS THAT YOU IMMEDIATELY FIND A PRODUCT THAT DOES MEET YOUR NEEDS AND EXPECTATIONS.

RESPONSIBLE FIREARM OWNERSHIP

The Company is not responsible for your use or misuse of any firearm used in conjunction with the product. The Company does not recommend or endorse the use and/or purchase of firearms. But, again, there is probably some greedy attorney out there that thinks you, as the customer, need to be specifically advised by the Company about responsible firearm ownership. First, the Company, again, specifically refers the customer to the instructions provided by the firearm manufacturer. Those instructions, professional advice, and information from law enforcement are the best sources of instructions for responsible firearm ownership.

NEVER rely on a firearm's safety mechanism to protect you or others from unsafe firearm handling.

NEVER touch the trigger of a firearm until you are ready to shoot.

NEVER shoot until you have gained a knowledge and an understanding of your target and backstop (what will the bullet hit if you miss or if it passes through the target).

NEVER shoot a firearm if the barrel is not completely free of obstructions or debris. If anything is in the barrel, follow the firearm manufacturer's instructions for removing the ammunition and the obstruction.

NEVER let mud, snow, or water enter the barrel of a firearm.

NEVER point the muzzle of a firearm at you or any other person, or any other object you do not intend to shoot.

NEVER use a firearm if you have taken drugs or alcohol. Your judgment, vision, and physical abilities may be impaired.

NEVER operate a firearm if you are taking medications, without first obtaining the advice and consent of a doctor.

NEVER operate a firearm without first getting instructions from a firearm instructor.

NEVER operate a firearm if you have not first become acquainted with the firearm and the safety features of the firearm.

NEVER store a firearm that is loaded, so that it cannot be fired unintentionally.

NEVER transfer a firearm to another person, without first requesting that the person check the magazine and chamber to ensure the firearm is unloaded.

NEVER take another person's word that a firearm is unloaded. Always check to see if the chamber and magazine are unloaded.

NEVER drop a firearm. The firearm may unintentionally discharge.

NEVER put your hand or any other body part over the muzzle of a firearm.

ALWAYS keep any firearm pointed in a safe direction.

ALWAYS store a firearm in a secure place; know and obey all firearm storage and possession laws.

NO FIREARM SHOULD BE USED UNTIL THE PURCHASER HAS REVIEWED AND UNDERSTANDS ALL OF THE INSTRUCTIONS AND WARNINGS PROVIDED BY THE FIREARM MANUFACTURER.

LIABILITY RELEASE:

AS PART OF THE SPECIFIC CONSIDERATION FOR THE PURCHASE OF THE PRODUCT, PURCHASER EXPRESSLY AGREES THAT ON BEHALF OF HIMSELF, HIS DESCENDANTS, DEPENDENTS, HEIRS, EXECUTORS, ADMINISTRATORS, ASSIGNS, AND SUCCESSORS, HE OR SHE FULLY, FINALLY AND FOREVER RELEASES AND DISCHARGES THE COMPANY, AND ITS PAST AND PRESENT PARENTS, SUBSIDIARIES AND AFFILIATES, AND ITS PAST AND PRESENT PREDECESSORS, SUCCESSORS, ASSIGNS, REPRESENTATIVES, OFFICERS, MEMBERS, AGENTS AND EMPLOYEES, FROM ANY AND ALL CLAIMS AND RIGHTS OF ANY KIND THAT PURCHASER MAY HAVE, WHETHER NOW KNOWN OR UNKNOWN, SUSPECTED OR UNSUSPECTED, INCLUDING, BUT NOT LIMITED TO, ARISING OUT OF OR IN ANY WAY CONNECTED WITH PURCHASER'S PURCHASE OR USE OF THE PRODUCT. ONLY THE ABOVE-REFERENCED LIMITED WARRANTY SURVIVES THIS RELEASE AND WAIVER. THESE CLAIMS AND RIGHTS RELEASED BY PURCHASER INCLUDE, BUT ARE NOT LIMITED TO, CLAIMS UNDER CIVIL OR STATUTORY LAWS, COMMON LAW, CONTRACT LAW, OR TORT LAW, INCLUDING, BUT NOT LIMITED TO, BREACH OF WARRANTY, BREACH OF EXPRESS WARRANTY, BREACH OF IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, NEGLIGENCE, PRODUCT LIABILITY, DEFECTS IN DESIGN, MANUFACTURING DEFECTS, FAILURE TO WARN, NEGLIGENT INFLICTION OF EMOTIONAL DISTRESS, ANY AND ALL CLAIMS FOR ATTORNEYS' FEES OR COSTS, AND ANY AND ALL CLAIMS RELATING, DIRECTLY OR INDIRECTLY TO THE PRODUCT. PURCHASER REPRESENTS THAT HE OR SHE KNOWS OF NO CLAIM THAT HE OR SHE HAS THAT HAS NOT BEEN RELEASED OR WAIVED BY THIS PARAGRAPH. IF PURCHASER DOES NOT AGREE WITH THESE TERMS, HE OR SHE MAY RETURN THE UNUSED PRODUCT TO THE COMPANY FOR A FULL REFUND. THESE DISCLAIMERS MAY BE ALTERED BY COMPANY FOR ANY REASON AND AT ANY TIME. REFER TO WWW.GUNCASKET.COM FOR UPDATED INFORMATION.

Congratulations!

Congratulations on your purchase of a Gun Casket™ gun safe. We've worked hard to create the World's Fastest Opening Shotgun Safe. Our innovative designs and patent pending features are created to help you get a weapon in your hands as fast as possible during an emergency.

What Makes Gun Casket the World's Fastest Opening Shotgun Safe?

- Three point lock gives you high security and a ¼ turn of the knob offers fast access to your weapon.
- Stores almost anywhere. The sooner you get to your Gun Casket the faster you get to your gun.
- Dedicated for one shotgun. No sorting through guns, just grab, point and—the rest is up to you.

Other Fancy Features.

- Pry resistant tongue and groove lid. **(Warning: Just like any door, the lid does open and close. If your fingers (or anyone else's) are in the way they may be pinched. Don't try to close the lid with your fingers or other body parts in the way! That could really hurt. And, don't close your fingers in any door or window because, if you do, you won't be able to operate the combination lock on your Gun Casket very well.)**
- Aluminum frame will never rust. The material is tempered for added strength and durability.
- Anodized coating creates a super hard, scratch resistant layer that is nearly as tough as diamonds.
- 50" storage area holds most shotguns, with extra space for backup gun, knife, flashlight, beef jerky, etc.
- Innovative design makes Gun Casket easy on the eyes and hard on the criminals.
- Proudly assembled in the USA!

Gun Casket™, the casket shape of the box, and the silver metallic anodized color resembling a casket, the slogan "The Safe Alternative," and the Gun Casket logo are trademarks of Gun Casket, LLC. The Gun Casket logo is a copyright of Gun Casket. Gun Casket safes are patent pending.